

## **CERTIFICATION OF WORK SERVICE CALL**

(To be completed by the Contractor and saved in the Contractor's CMMS)

FACID/Building: \_\_\_\_\_ Date of Visit: \_\_\_\_\_

#### Contractor Personnel on Site:

1. \_\_\_\_\_
2. \_\_\_\_\_
3. \_\_\_\_\_
4. \_\_\_\_\_
5. \_\_\_\_\_
6. \_\_\_\_\_

## Service Call Number

CSS# \_\_\_\_\_ WO# \_\_\_\_\_

## Description of Repairs

---

---

---

---

## **CERTIFICATION OF WORK**

To be signed by the Contractor:

Print Name: \_\_\_\_\_ Date: \_\_\_\_\_

Signed: 

To be signed by Facility Manager:

By signing the Certification of Work, the said government representative signature does not constitute acceptance of any work performed by the contractor, it only acknowledges that the contractor was on-site during the identified timeline:

Print Name/Rank: \_\_\_\_\_ Date: \_\_\_\_\_

Signed: 

E-Mail:

WILKERSON  
F30-08-000A E98

KRUMAN EQUIPMENT CO.  
PITTSBURGH, PA. (412) 261-4647

