

CERTIFICATION OF WORK	
(To be completed by the Contractor and saved in the Contractor's CMMS)	
FACID/Building: <u>NY23 BGM 330</u>	Date of Visit: <u>7/26</u>
Location Address: <u>FT TOTTEN</u>	
Contractor Personnel on Site:	
<u>JENNIFER TAMMY</u>	
Work Performed: <u>OPAS Prebler with #5 AC UNIT</u>	
Service Calls - PO/CSS#	
<u>CL19426 wo 23384 for 10004-1654</u>	
Please take pictures and send with quote	
CERTIFICATION OF WORK	
To be signed by the Contractor:	
Print Name: <u>TOTEN woman</u>	Date: <u>7/16</u>
Signed: <u>pw</u>	
To be signed by Facility Manager:	
I certify that the above named individuals representing the Contractor arrived on site.	
Print Name/Rank: <u>Louis Corbo</u>	Date: <u>JULY 26, 2013</u>
Signed: <u>Louis Corbo</u>	
Email: <u>Louis - A. Corbo - CIV @Army.mil</u>	

