

CERTIFICATION OF WORK	
(To be completed by the Contractor and saved in the Contractor's CMMS)	
FACID/Building: <u>NYN3 CDR 12</u>	Date of Visit: <u>9/5/23</u>
Location Address: <u>FT TOTTEN NY</u>	
Contractor Personnel on Site: <u>JERRY TERRY</u>	
Work Performed: <u>CHECK OUT APC WIRE BM 1010 D LOCATED</u>	
Service Calls - PO/CSS# <u>01596887 WD 24703 Po 10004102T</u>	
Please take pictures and send with quote	
CERTIFICATION OF WORK	
To be signed by the Contractor:	
Print Name: <u>Terry Wilson</u>	Date: <u>9/5/23</u>
Signed: <u>[Signature]</u>	
To be signed by Facility Manager:	
I certify that the above named individuals representing the Contractor arrived on site.	
Print Name/Rank: <u>Louis Corbo</u>	Date: <u>Sept 6, 2023</u>
Signed: <u>[Signature]</u>	
Email: <u>Louis.A.Corbo-CIV@Army.mil</u>	

