




NOTICE:
FOR WARRANTY ON THIS
COMPRESSOR TO BE VALID, THE
COMPRESSED AIR AND GAS
INSTITUTE'S MAINTENANCE
INSTRUCTIONS MUST BE FOLLOWED

MAINTENANCE INSTRUCTIONS

CAUTION
TURN OFF POWER BEFORE SERVICING

The following instructions are listed as general guidelines. Refer to manufacturer's manual for detailed instructions. It is the user's responsibility to ensure the safety of all checks.

CAUTION

- Check for proper oil level.
- Check for correct pressure flow direction and type.
- Check for any unusual noise or vibration.
- Check air filter.
- Check all external parts of compressor and drive.
- Check pressure should be tested regularly to see that it stays at 100 psi.
- Impact parts are system for leaks.
- Inspect all the connections and change if necessary.
- Check both pressure and temperature.
- Change oil.
- Inspect valve assembly.

Worked at
COMPRESSED AIR AND GAS INSTITUTE
CAGI