

CERTIFICATION OF WORK

(To be completed by the Contractor and saved in the Contractor's CMMS)

FACID/Building: P166 Date of Visit: 2/15/19

Contractor Personnel on Site:

1. Sentry 2. _____

Work Performed:

Preventive Maintenance - Services Completed (Annual, Quarterly, Monthly, equipment identification, etc.)

1. WO# _____

Service Calls – Service Call Number and Description

1. CSS# 17107
2. CSS# _____
3. CSS# _____

Look at electric heater in stairwell &
6-9 Autom. A.C. vents

To be signed by the Contractor:

Print Name: Duke Date: 2/15/19

Signed: Duke

To be signed by Facility Manager:

I certify that the above named individuals representing the Contractor arrived on site and to the best of my knowledge, completed the stated work listed:

Print Name/Rank: _____ Date: 2/15/19

Signed: _____

E-Mail: _____

Signature
timothy peters





SENTRY MECHANICAL
1724 Leechburg Road
Pittsburgh, PA 15235
(412) 795-3040
Fax (412) 795-3208
One copy per piece of equipment

MECHANICAL SYSTEM
EVALUATION

Date: _____
Customer Name: CMJ Army Reserve
Customer Contact: Jim Perry
Address: 99 Soldiers Ln
Job Location: Conynghs PA 15006
Equipment Type: Electric Unit Heater
Model #: MUR05H
Serial #: 0304
Volts: 140
Equipment #: PA169-01
Phase: 3
Filter(s) (qty, size & type):
Accessability: GLT Ladder
Evaluation: Found Bad Fan Motor
Replacement of Fan Motor & Testing System
Rephasing Extra Heater & Testing
Quote
Grange Quote # 2039618016

Photos Attached: Yes ☐ No ☐
Other: _____
Status: Incomplete ☐ Complete ☐
Priority 1-5: ☐ (5 Being High)

Reviewed By: WHITE - Service Department
Date: _____
Service Tech: YELLOW - Job File
Date: _____
PINK - Technician



MODEL

MUH0541

UNIT 1300

0304

VOLTS AC
60 HZ
480KILOWATTS
5PHASE
3MOTOR
VAC
480AMP
.15CONTROLS
VAC
247/42 LISTED
ROOM HEATER

AIR FLOW	MINIMUM MOUNTING CLEARANCE				FLOOR
	SIDE	BACK	CEILING		
HORIZ.	6 IN.	9.5 IN.	2 IN.		7 FT.
VERT.	18 IN.	18 IN.	6 IN.		7 FT.

WARNING: DO NOT TURN LOUVERS ABOVE LEVEL OF THE UNIT.
DISCONNECT POWER BEFORE SERVICING. IF EXTERNAL
CONTROL IS USED, ALSO DISCONNECT EXTERNAL POWER SUPPLY.

NE PAS RELEVER LES LAMES AU-DEL À DU NIVEAU
PRÉVU DE L'APPAREIL. METTRE HORS TENSION
AVANT DE PROCÉDER À L'ENTRETIEN.
SI UNE COMMANDE EXTERNE EST UTILISÉE, COUPER
AUSSI L'ALIMENTATION EXTERNE. ASSURER UN
DÉGAGEMENT D'AU MOINS 6 PI ENTRE L'APPAREIL
DE CHAUFFAGE ET LE PLANCHER.

PRECAUCION: NO VOLTEAR LAS REJILLAS POR ENCIMA DEL NIVEL
DE LA UNIDAD. DESCONECTAR EL CALEFACTOR ANTES DE DARLE
SERVICIO. SI SE USA UN CONTROL EXTERNO, TAMBIEN DEBE
DESCONECTARSE DE LA CORRIENTE.

THE LOWER PART