

CASEY DAVIS

CERTIFICATION OF WORK

(To be completed by the Contractor and saved in the Contractor's CMMS)

FACID/Building: MD003 Date of Visit: 12/12/19

Contractor Personnel on Site:

1. CASEY DAVIS 4. \_\_\_\_\_  
2. \_\_\_\_\_ 5. \_\_\_\_\_  
3. Brian DAVIS 6. \_\_\_\_\_

Service Calls – Service Call Number and Description

WOT# 4400 CSS# 13614  
1. \_\_\_\_\_  
2. \_\_\_\_\_  
3. \_\_\_\_\_

Install AH unit - Tie in Condenser unit  
CERTIFICATION OF WORK

To be signed by the Contractor:

Print Name: CASEY DAVIS Date: 12/12/19

Signed: [Signature]

To be signed by Facility Manager:

By signing the Certification of Work, the said government representative signature does not constitute acceptance of any work performed by the contractor, it only acknowledges that the contractor was on-site during the identified timeline:

Print Name/Rank: R. S. Daniels Date: 12 DEC 2019

Signed: [Signature]

E-Mail: roderick.s.daniels.civ@mail.mil









<b>Run Program</b> <input type="button" value="Run Program"/>	<b>Set Program</b>			<b>Set Temperature</b>		<b>Change Time/Temp</b>
<b>Temporary Occupied</b> <input type="button" value="Temporary Occupied"/>	<b>Occupied Start Time</b> <input type="button" value="Occupied Start Time"/>	<b>Unoccupied Start Time</b> <input type="button" value="Unoccupied Start Time"/>	<b>Day</b> <input type="button" value="Day"/>	<b>Occupied Temp</b> <input type="button" value="Occupied Temp"/>	<b>Unoccupied Temp</b> <input type="button" value="Unoccupied Temp"/>	<input type="button" value="Up Arrow"/>
<b>Continuous Unoccupied</b> <input type="button" value="Continuous Unoccupied"/>	<b>Set Current Day/Time</b> <input type="button" value="Set Current Day/Time"/>	<b>Clear Start Time</b> <input type="button" value="Clear Start Time"/>	<b>Copy</b> <input type="button" value="Copy"/>	<b>Heat/Cool Settings</b> <input type="button" value="Heat/Cool Settings"/>		<input type="button" value="Down Arrow"/>
				<b>System</b> <input type="button" value="System"/>	<b>Fan</b> <input type="button" value="Fan"/>	

This thermostat provides security which locks out some or all of the keys to prevent tampering. If the display does not respond, the keyboard may be locked out. Contact your installer.

**Set clock and day**

1. Press "Set Current Day/Time" key.
2. Press the Up or Down arrow keys to set correct time.
3. Press the "Day" key to set correct day.
4. Press the "Run Program" when complete.

**Using the Temporary Occupied feature**

Press the "Temporary Occupied" key to activate occupied temperature settings.

**Using Continuous Unoccupied feature**

1. Press the "Continuous Unoccupied" key to activate unoccupied temperature settings for an indefinite period of time.
2. Press the "Run Program" key to return to normal operation.

**System and Fan Keys**

Press the "System" key to select heating or cooling equipment or automatically change between heating and cooling. Press the "Fan" key to select continuous or auto fan operation. In the Auto position, the fan is controlled by the heating or cooling equipment.

Note: If "Auto Only" is displayed, the thermostat has been configured for auto only and cannot be modified.