

CERTIFICATION OF WORK

(To be completed by the Contractor and saved in the Contractor's CMMS)

FACID/Building: 80th Date of Visit: 8/9/21
Contractor Personnel on Site:

1. Morgan's Elec. 2. _____

Work Performed: General Inspection of systems

Preventive Maintenance - Services Completed (Annual, Quarterly, Monthly, equipment identification, etc.)

1. WO# 149679 14679 _____


Service Calls – Service Call Number and Description

1. CSS# 31834 _____
2. CSS# _____
3. CSS# _____

CERTIFICATION OF WORK

To be signed by the Contractor:


Print Name: Earl Ward Date: 8/9/21

Signed: 

To be signed by Facility Manager:

I certify that the above named individuals representing the Contractor arrived on site and to the best of my knowledge, completed the stated work listed:

Print Name/Rank: Carlos M. Nieves | CIV Date: Aug 9, 2021.

Signed: 

E-Mail: rodriguez.c.nieves.civ@mail.mil

Device 109 (Zone 1-1)

BACtalk Edit View Tools Help

Previous

ISU and Warnings

Custom Screen Configuration

SYSTEM and FAN

Humidifier/Dehumidifier

VLC Device Properties

Operating Mode

0

0-Microset (Occupancy)

1-Visionpro (Setpoint)

Setpoint Mode

Valid only in
VisionPro mod

Input/Output Settings

Sensed Temperature	69.5	AV 104
Sensed Humidity	58.3	AV 105
	4095.0	AI 0
	4095.0	AI 1
	4095.0	AI 2
		BO 0
		BO 1
		BO 2
		BO 3
		BO 4
		BO 5
	43.7	AO 0
	0.0	AO 1
		BI 0

Deny Schedule

Deny Schedule

Deny Permanen

Deny Vacation

Deny Clock Adj

FS PIN A

Device 110 (Zone 1-2)

BACtalk Edit View Tools Help

Previous

SYSTEM an

ISU and Warnings

Humidifier/Deh

Custom Screen Configuration

VLC Device Pro

Operating Mode

0

0-Microset (Occupancy)

1-Visionpro (Setpoint)

Input/Output Settings

Sensed Temperature

71.2

AV 104

Sensed Humidity

52.4

AV 105

4095.0

AI 0

4095.0

AI 1

4095.0

AI 2



BO 0



BO 1



BO 2



BO 3



BO 4



BO 5

100.0

AO 0

Device 111 (Zone 1-3)

BACtalk Edit View Tools Help

Previous

SYSTEM and

ISU and Warnings

Humidifier/Dehum

Custom Screen Configuration

VLC Device Prop

Operating Mode **0**

Set

0-Microset (Occupancy)

Vali

1-Visionpro (Setpoint)

Visi

Input/Output Settings

Sensed Temperature	69.5	AV 104
--------------------	------	--------

Sensed Humidity	57.4	AV 105
-----------------	------	--------

	4095.0	AI 0
--	--------	------

	4095.0	AI 1
--	--------	------

	4095.0	AI 2
--	--------	------

		BO 0
--	---	------

		BO 1
--	---	------

		BO 2
--	---	------

		BO 3
--	---	------

		BO 4
--	---	------

Deny

Deny

Device 112 (Zone 1-4)

BACtalk Edit View Tools Help

Previous

ISU and Warnings

Custom Screen Configuration

SYSTEM and FAN

Humidifier/Dehumidifier

VLC Device Properties

Operating Mode

0

0-Microset (Occupancy)

1-Visionpro (Setpoint)

Setpoint Mo

Valid only in

VisionPro m

Input/Output Settings

Sensed Temperature

71.8

AV 104

Sensed Humidity

52.7

AV 105

4095.0

AI 0

4095.0

AI 1

4095.0

AI 2



BO 0



BO 1



BO 2



BO 3



BO 4



BO 5

Deny Schedu

Deny Schedu

Deny Perman

Device 113 (Zone 1-5)

BACtalk Edit View Tools Help

Previous

SYSTEM and FAULT

ISU and Warnings

Humidifier/Dehumidifier

Custom Screen Configuration

VLC Device Properties

Operating Mode

Setpoint

0-Microset (Occupancy)

Valid on

1-Visionpro (Setpoint)

Visionpro

Input/Output Settings

Sensed Temperature	70.5	AV 104
Sensed Humidity	59.2	AV 105
	4095.0	AI 0
	4095.0	AI 1
	4095.0	AI 2
	☒	BO 0
	☒	BO 1
	☒	BO 2
	☒	BO 3
	☒	BO 4

Deny S

Device 114 (Zone 2-1)

BACtalk Edit View Tools Help

Previous

SYSTEM an

ISU and Warnings

Humidifier/Deh

Custom Screen Configuration

VLC Device Pro

Operating Mode

0-Microset (Occupancy)

1-Visionpro (Setpoint)

Input/Output Settings

Sensed Temperature	71.8	AV 104
--------------------	-----------------------------------	--------

Sensed Humidity	49.1	AV 105
-----------------	-----------------------------------	--------

	4095.0	AI 0
--	-------------------------------------	------

	4095.0	AI 1
--	-------------------------------------	------

	4095.0	AI 2
--	-------------------------------------	------

	☒	BO 0
--	-------------------------------------	------

	☒	BO 1
--	-------------------------------------	------

	☒	BO 2
--	-------------------------------------	------

	☒	BO 3
--	-------------------------------------	------

Device 115 (Zone 2-2)

BACTalk Edit View Tools Help

Previous

SYSTEM and P

ISU and Warnings

Humidifier/Dehum

Custom Screen Configuration

VLC Device Proper

Operating Mode **0**

Setp

0-Microset (Occupancy)

Valid

1-Visionpro (Setpoint)

Vision

Input/Output Settings

Sensed Temperature		70.2	AV 104
Sensed Humidity		53.6	AV 105
		4095.0	AI 0
		4095.0	AI 1
		4095.0	AI 2
		☒	BO 0
		☒	BO 1
		☒	BO 2
		☒	BO 3
		☒	BO 4

Deny

Device 116 (Zone 2-3)

BACtalk Edit View Tools Help

Previous

SYSTEM

ISU and Warnings

Humidifier/D

Custom Screen Configuration

VLC Device

Operating Mode

0-Microset (Occupancy)

1-Visionpro (Setpoint)

Input/Output Settings

Sensed Temperature	73.7	AV 104
--------------------	-----------------------------------	--------

Sensed Humidity	45.8	AV 105
-----------------	-----------------------------------	--------

	4095.0	AI 0
--	-------------------------------------	------

	4095.0	AI 1
--	-------------------------------------	------

	4095.0	AI 2
--	-------------------------------------	------

	☒	BO 0
--	-------------------------------------	------

	☒	BO 1
--	-------------------------------------	------

Device 117 (Zone 2-4)

BACtalk Edit View Tools Help

Previous

SYSTEM

ISU and Warnings

Humidifier/D

Custom Screen Configuration

VLC Device

Operating Mode

0

0-Microset (Occupancy)

1-Visionpro (Setpoint)

Input/Output Settings

Sensed Temperature

73.9

AV 104

Sensed Humidity

47.8

AV 105

4095.0

AI 0

4095.0

AI 1

4095.0

AI 2

 BO 0

 BO 1

Device 119 (Zone 2-6)

BACtalk Edit View Tools Help

Previous

SYSTEM

ISU and Warnings

Humidifier/D

Custom Screen Configuration

VLC Device

Operating Mode

0-Microset (Occupancy)

1-Visionpro (Setpoint)

Input/Output Settings

Sensed Temperature	70.2	AV 104
Sensed Humidity	54.3	AV 105
	4095.0	AI 0
	4095.0	AI 1
	4095.0	AI 2
	☒ BO 0	BO 0
	☒ BO 1	BO 1

i

Status

Detail

Help

Adjust

Boiler

146^F

Standby

0

^{kbtu}
hr



i

Status

Boiler 1

Detail

134^F

0%

Help

Standby

Adjust

er System)

Help

OSA Temp 93.3 OA °F


Monday, 8/9/2021 4:32:05P

Boiler 1 Off
Boiler 1 OK

Boiler 2 Running
Boiler 2 OK

Boiler 3 Off
Boiler 3 OK

Boiler 4 Off
Boiler 4 OK



ontrol

HW System: Enabled

OA Temp 93.3

p System Lockout 100.0

AHU-1 Heed's HW

AHU-2 Heed's HW

Occ Fan Coils req HW 0

Occ Fan Coils to Start 10

HW Supply Temperature

Manual SP 140

☒ Use Reset SetPoint

OA Temp 93.3

Current Setpoint 140.0



Envision For