

PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST
SUMP PUMP

SITE AND BLDG #: NY023-319

MECHANIC
SIGNATURE: *Deen Rowe*

DATE: *12/10/21*

LOCATION/RM #: *N/A*

START TIME: *3pm*

FINISH TIME: *3pm*

Site Location	WO #	Asset #	PM #	Manufacturer	Model Number	Serial #	Asset Description	Asset Location
NY023-319	15334	9548	PM-QT-9548				J-31 1-pc Sump Pump, Electric Rm A005	

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)	
		YES	NO	SPECIAL INSTRUCTIONS	
1	In addition to the procedure(s) outlined in this standard, the equipment manufacturer's recommended maintenance procedure(s) and/or instruction(s) shall be strictly adhered to.				
2	Schedule outage with operating personnel.				
3	Follow lock out/tag out procedures always. De-energize or discharge all hydraulic, electrical, mechanical, or thermal energy prior to beginning work.				
4	If the material removed from the pump is hazardous, contact the Regional S&EM office for disposal instructions.				
5	If strainer cleaning requires removal of pump unit which should be considered a repair and not general maintenance.				
6	Excessive sediment and debris, not removed by flushing the pit should be handled on a project basis, and not considered under this standard.				
TO BE PERFORMED AT EACH INSPECTION SERVICE					

1	Remove cover plates and flush pit.				
2	Inspect check valve.				
3	Inspect interior of pit for cracks.				
4	Inspect cover plate gaskets and replace if necessary.				
5	Insure the unit is operating properly, report any deficiencies				
6	Clean up work area and remove all debris.				

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency. To be performed by: General Maintenance Worker **Additional Notes:**

*Asset # 9548 Does Not Exist Please Remove
 from PM List. Sump Pump is not being used in
 Building 319.

