

REVIEWED

By Michael Merchan at 7:48 am, Jan 09, 2019

PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST **MANUAL/AUTOMATIC OVERHEAD DOORS**

SITE AND BLDG #: VA051-01

MECHANIC
SIGNATURE

Andy Bird

DATE:

1-8-19

LOCATION/RM #:




START TIME:

9AM

FINISH TIME:

3PM

Site Location	WO #	Asset #	PM #	Manufacturer	Model Number	Serial #	Asset Description	Asset Location
VA051-01	6981	7696		Overhead Door	RDB-51	N/A	J-1502000-52 1-pc Overhead Door, Steel, Roll Up, 12Wx20H	Drill Hall
VA051-02	7078	8030		Overhead Door	RDB-51	N/A	J-1502000-56 5-pc Overhead Door, Steel, Roll Up, 24Wx14H	AMSA
VA051-03	7076	7965		Lift Master	N/A	N/A	J-1502000-56 1-pc Overhead Door, Steel, Roll Up, 10Wx10H	Cage
VA051-04	7075	7963		Lift Master	N/A	N/A	J-1502000-56 1-pc Overhead Door, Steel, Roll Up, 10Wx10H	Cage

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)
		YES	NO	
SPECIAL INSTRUCTIONS				
1	In addition to the procedure(s) outlined in this standard, the equipment manufacturer's recommended maintenance procedure(s) and/or instruction(s) shall be strictly adhered.			
2	Follow lock out/tag out procedures at all times. De-energize or discharge all hydraulic, electrical, mechanical, or thermal energy prior to beginning work.			
TO BE PERFORMED AT EACH INSPECTION SERVICE				
1	Check with door operating personnel for any known deficiencies.			

2	Inspect general arrangement of door and mechanism, mountings, standards, wind locks, anchor bolts, counterbalances, weather stripping, door sweeps etc. Clean, tighten, and adjust repair as required.	✓		
3	If applicable, operate with power from start to stop and at intermediate positions. Observe performance of various components, such as brake, limit switches, door operating speed, motor, gear box, etc. Clean and adjust as needed.	✓		
4	Check operation of safety edges, stops, electric eye, treadle, or other operating devices. Clean and make required adjustments or repairs.		✓	N/A
5	Check manual operation. Note brake release, motor disengagement, functioning or hand pulls, chains sprockets, clutch, etc.	✓		
6	If applicable, examine all wiring, motor, starter, push button, etc., blow out or vacuum if needed.	✓		
7	If applicable, inspect gear box, change or add oil as required.	✓		
8	Perform required lubrication. Remove old or excess lubricant.	✓		
9	Clean unit and mechanism thoroughly. Touch up paint where required.	✓		
10	Clean up and remove all debris.	✓		

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency. To be performed by: General Maintenance Worker **Additional Notes:**



VA051-04
Overhead door operator has failed.
CM Needed