

**PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST**  
**AIR COOLED CHILLER, PACKAGE UNIT**

**SITE AND BLDG #:** Gaithersburg MD013

**MECHANIC  
SIGNATURE:**

**DATE:** 11/3/20

**LOCATION/RM #:** exterior **WO#** 13020 **ASSET #** 1989

**START TIME:**

8:30.

**FINISH TIME:** 10:00

<b>CHECK POINT</b>	<b>CHECKPOINT DESCRIPTION</b>	<b>TASK COMPLETE</b>		<b>NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)</b>
		<b>YES</b>	<b>NO</b>	
<b>SPECIAL INSTRUCTIONS</b>				
1	Follow lock out/tag out procedures at all times. De-energize or discharge all hydraulic, electrical, mechanical, or thermal energy prior to beginning work.	✓		
2	No intentional venting of refrigerants is permitted. During the servicing, maintenance, and repair of refrigeration equipment, the refrigerant must be recovered.	✓		
3	Whenever refrigerant is added or removed from equipment, record the quantities on the appropriate forms. Forms to be maintained by technician in universal waste binder.	✓		
4	Recover, recycle, or reclaim the refrigerant as appropriate.	✓		
5	If disposal of the equipment item is required, follow regulations concerning removal of refrigerants and disposal of the item.	✓		
6	If materials containing refrigerants are discarded, comply with EPA regulations as applicable.	✓		
7	Refrigerant oils to be treated as hazardous waste.	✓		
8	Closely follow all safety procedures described in the Safety Data Sheet (SDS) for the refrigerant and all labels on refrigerant containers.	✓		
9	Remove access covers prior to accomplishing check points.	✓		
<b>TO BE PERFORMED AT EACH INSPECTION SERVICE</b>				
<b>CONDENSER</b>				
1	Remove debris from air screen and clean underneath unit.	✓		
2	Pressure wash coil with proper cleaning solution.	✓		
3	Straighten fin tubes with fin comb.	✓		
4	Check electrical wiring and tighten loose connections. Check fused disconnect switches for condition and operation, contactors	✓		
5	Check mounting for tightness.	✓		
6	Check for corrosion. Clean and treat with inhibitor as needed.	✓		
7	Check fan or blower for bent or damaged blades and imbalance.	✓		
8	Lubricate shaft and motor bearings on fans and remove old or excess lubricant, if applicable.	✓		
9	Inspect pulleys, belts, couplings, etc.; adjust tension and tighten mountings as necessary. Change badly worn belts. Multi-belt drives should be replaced with matched sets.	✓		
<b>EVAPORATOR</b>				
1	Inspect evaporator for any obvious deficiencies.	✓		
2	Inspect plumbing, valves and flanges for leaks and correct as needed.	✓		
<b>COMPRESSOR(S)</b>				
1	Lubricate drive coupling, if applicable.	✓		
2	Lubricate motor bearings (non-hermetic), if applicable.	✓		
3	Check bearings for vibrations or unusual noises.	✓		
4	Leak test unit with soap test or electronic device.	✓		
5	Check compressor oil level., if applicable.	✓		
6	Run machine; check action of controls, relays, switches, etc. to see that: a. Compressor(s) run at proper settings. b. Suction and discharge pressures are proper.	✓		
7	Check vibration eliminators. Replace as necessary.	✓		
	Document AMP draw on compressors	na	L1	See notes
8	Check safety controls for high pressure cut off.	✓	L2	L3
<b>CONTROLS</b>				
1	Record chilled water supply and return temps and Humidity .	✓		

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency.

To be performed by: HVAC Technician

**Additional Notes:**

**unit shut down for winter**

