

CERTIFICATION OF WORK PREVENTIVE MAINTENANCE

(To be completed by the Contractor and saved in the Contractor's CMMS)

FACID/Building: VA701-01-02 Date of Visit: 2/11/2021

Contractor Personnel on Site:

1. <u>Richard Walker</u>	3. _____
2. _____	4. _____

Work Performed:

Preventive Maintenance - Services Completed (Annual, Quarterly, Monthly, equipment identification, etc.)

1. _____
2. _____
3. _____
4. _____
5. _____

CERTIFICATION OF WORK

To be signed by the Contractor:

Print Name: Richard Walker Date: 2/11/2021
Signed: Richard Walker

To be signed by Facility Manager:

By signing the Certification of Work, the said government representative signature does not constitute acceptance of any work performed by the contractor, it only acknowledges that the contractor was on-site during the identified timeline:

Print Name/Rank: Terry Casey Date: 2/11/2021
Signed: Terry Casey

E-Mail: _____

PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST
WATER SOFTENER

SITE AND BLDG #: VA701-01

LOCATION/RM #: 133 WO# 13579 ASSET # 34239

MECHANIC
SIGNATURE: *Richard Walker*

DATE: 2/11/2021

START TIME: 9:30 AM FINISH TIME: 6 PM

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)
		YES	NO	
SPECIAL INSTRUCTIONS				
1	Follow lock out/tag out procedures at all times. De-energize or discharge all hydraulic, electrical, mechanical, or thermal energy prior to beginning work.	✓		
TO BE PERFORMED AT EACH INSPECTION SERVICE				
1	a. Drain the tank. b. Examine the exterior of the tank including fittings, gauges, manholes, and handholes for signs of leaks or corrosion. c. Inspect structural supports and insulation or coverings for defects or deterioration. d. Open the tank and remove rust or chemical deposits from interior tank surfaces. e. Inspect the interior of the tank for pitting, cracks, and other defects.	✓		
2	Lime Water Softener f. Dismantle vacuum breakers. Inspect stem, valve seat and spring. Repair as required. g. Inspect, clean, and flush the nozzle ring. h. Remove vent condenser heads and clean the tubes. i. Inspect and clean the sight glass, level indicators, and level controllers.	✓		
3	Zeolite Water Softener j. Check the filter bed for proper level	✓		
4	Anthracite Water Softener. k. Check the filter bed for proper level	✓		

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency.

To be performed by: General Maintenance Worker

Additional Notes: