

WATER HEATER INVENTORY

PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST DOMESTIC HOT WATER HEATER - ELECTRIC GAS

SITE AND BLDG #: NY024-208 MECHANIC SIGNATURE: [Signature] DATE: 8/3/2020

LOCATION/RM #: _____ WO# _____ ASSET # _____ START TIME: _____ FINISH TIME: _____

ITEM NO.	DESCRIPTION	TEST RESULTS		NOTES
		YES	NO	
1	In addition to the procedure(s) outlined in this standard, the equipment manufacturer's recommended maintenance procedure(s) and/or instruction(s) shall be strictly adhered to.	☒		
2	Follow lock out/tag out procedures at all times. De-energize or discharge all hydraulic, electrical, mechanical, or thermal energy prior to beginning work.	☒		
1	Attach drain hose. Drain several gallons from tank to remove sediment.	☒		
2	Manually check operation of safety valve. Check for corrosion around valve. Verify the safety valve inspection tag is in place. Ensure that no personnel are in area of relief piping discharge.	☒		DRAIN WATER HEATER
3	Check all connections - electric and water. Tighten as necessary. Ensure power is disconnected to electric heaters prior to checking connections.	☒		WATER HEATER OK
4	Check operation/ setting of aquastat. Check hot water temperature with dial thermometer, set aquastat at minimum value required for all uses.	☒		
5	Check amperage draw of upper and lower elements and compare to name plate data.	☒		
6	Clean element contacts, and check for proper closing under load.	☒		
7	Clean pump, controls, switches, and starters. Check condition of pump seal or packing, and replace as required.	☒		
8	If applicable, Remove and inspect Anode, replace if necessary.	☒		
9	Clean up work area and remove trash.	☒		

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency.

To be performed by: General Maintenance Worker

Additional Notes:

ASSET # - W.O.#

PK-25-9680-9559- MECHANICAL ROOM

PK-25-9681-9560- MECHANICAL ROOM

PK-25-9682-9561- ROOM 119

Page 1 of 1