

PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST CIRCULATING AND BOOSTER PUMPS

SITE AND BLDG #: NY024-BOS 202 MECHANIC SIGNATURE: R. Hansen DATE: 8/5/2022

LOCATION/RM #: _____ WO# _____ ASSET # _____ START TIME: _____ FINISH TIME: _____

CHECK ITEM	DESCRIPTION	DATE	TIME	INITIALS	NOTES
1	In addition to the procedure(s) outlined in this standard, the equipment manufacturer's recommended maintenance procedure(s) and/or instruction(s) shall be strictly adhered to.	✓			
2	Follow lock out/tag out procedures at all times. De-energize or discharge all hydraulic, electrical, mechanical, or thermal energy prior to beginning work.	✓			
3	It is generally not a good idea to tamper with pumps using mechanical seals if they are otherwise performing properly. Since mechanical seals can cost as much as the pump, it is usually not cost effective to risk damaging the seal by performing an annual internal inspection of the pump.	✓			
1	Lubricate pump and motor bearings as per manufacturer's specifications.	✓			WBA GSK Pump
2	Bearings require lubrication atleast annually.	✓			4 hours
3	Inspect couplings and check for any pump seal leaks.	✓			
4	Check motor mounts and vibration pads	✓			
5	Tighten all pump flanges.	✓			
6	Visually check pump alignment and coupling	✓			
6	Inspect electrical connections	✓			

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency.
To be performed by: General Maintenance Worker

Additional Notes:

PKA- 190917-212- ✓
PKA- 190917-213- ✓
9653
9653