

**REVIEWED**

By Michael Merchan at 12:34 pm, Feb 04, 2019

**PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST**  
**REACH-IN REFRIGERATORS/ FREEZERS**

**SITE AND BLDG #:** WV010-01**LOCATION/RM #:** Room 121**MECHANIC  
SIGNATURE:***Patrick Davis***DATE:** 4 February 2019**START TIME:** 7:30**FINISH TIME:** 3:30

Site Location	WO #	Asset #	PM #	Manufacturer	Model Number	Serial #	Asset Description	Asset Location
WV010-01	7356	6790		True	T5-49 F	0859978	J-1502000-23 1-pc Freezer, 2 Section, Reach In, Electric	RM 121
WV010-01	7356	6911		continental	N/A	N/A	J-1502000-23 2-pc Refrigerator, 2 Section	RM 121

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)
		YES	NO	
<b>SPECIAL INSTRUCTIONS</b>				
1	Review manufacturer's instructions.	✓		
2	De-energize, lock out, and tag electrical circuits.	✓		
3	If appliance is disposed, follow regulations concerning removal of refrigerants and disposal of the appliance.	✓		
4	If materials containing refrigerants are discarded, comply with EPA regulations as applicable.	✓		
5	Closely follow all safety procedures described in the Safety Data Sheet (SDS) for the refrigerant and to all labels on refrigerant containers.	✓		
<b>TO BE PERFORMED AT EACH INSPECTION SERVICE</b>				
1	Check with operating or area personnel for any deficiencies; verify cleaning program.	✓		
2	Verify indicator light on; check compartment temperature.	✓		
3	Examine evaporator for proper clearances/slope and air flow.	✓		
4	Examine handles, hinges, and tightness of door closure.	✓		
5	Examine safety door release and fan shut down safety switch.	✓		
6	Inspect lighting for burnt out lamps.	✓		
7	Check starter panels and controls for proper operation, burned or loose contacts, and loose connections.	✓		

8	Clean evaporator coil, evaporator drain pan, blowers, fans, motors, and drain piping as required; lubricate motor(s).	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
9	Clean condenser coil and condensing unit section.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
10	Clean and inspect defrost evaporation trays/pans.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
11	Inspect defrost systems for proper operation, including timer; adjust as required. Have automatic defrosters adjusted as required so freezer will defrost during "Off Peak" hours	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
12	Check operation of thermostats; calibrated as required.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
13	Check coil superheat and adjust to manufacturers recommendations.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
14	Inspect and service all electric motors.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)
		YES	NO	
15	Inspect door gaskets for damage and proper fit; adjust gaskets as required and lubricate hinges with food grade oil.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
16	Check door gasket heater.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
17	Check box floor for water or ice accumulation.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
18	Check box for excessive ice build- up and open seams.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency. To be performed by: General Maintenance Worker **Additional Notes:**

\* Freezer is 'Out of Commission'... Corrective Measure Needed.  
 Bottom is Full of Mold. \*Assets need to be decommissioned from the asset inventory list

\* Refrigerator #2 is going bad, Corrective Measure Needed



