

PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST REACH-IN REFRIGERATORS/ FREEZERS

SITE AND BLDG #: 14116-01
LOCATION/RM #: 122A WO# _____ ASSET # _____

MECHANIC SIGNATURE: [Signature] DATE: 8/14/10
START TIME: _____ FINISH TIME: _____

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)
		YES	NO	
1	Review manufacturer's instructions.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
2	De-energize, lock out, and tag electrical circuits.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
3	If appliance is disposed, follow regulations concerning removal of refrigerants and disposal of the appliance.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4	If materials containing refrigerants are discarded, comply with EPA regulations as applicable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
5	Closely follow all safety procedures described in the Safety Data Sheet (SDS) for the refrigerant and to all labels on refrigerant containers.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
TO BE PERFORMED AT EACH INSPECTION SERVICE				
1	Check with operating or area personnel for any deficiencies, verify cleaning program.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	CLEAR COPPER SINE
2	Verify indicator light on; check compartment temperature.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	COIL & COIL
3	Examine evaporator for proper clearances/slope and air flow.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4	Examine handles, hinges and tightness of door closure.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
5	Examine safety door release and fan shut down safety switch.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6	Inspect lighting for burnt out lamps.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7	Check starter panels and controls for proper operation, burned or loose contacts, and loose connections.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8	Clean evaporator coil, evaporator drain pan, blowers, fans, motors, and drain piping as required; lubricate motor(s).	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
9	Clean condenser coil and condensing unit section.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
10	Clean and inspect defrost evaporation trays/pans.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
11	Inspect defrost systems for proper operation, including timer; adjust as required. Have automatic defrosters adjusted as required so freezer will defrost during "Off Peak" hours	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
12	Check operation of thermostats; calibrated as required.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
13	Check coil superheat and adjust to manufacturers recommendations.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
14	Inspect and service all electric motors.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Page 1 of 2

ASSN # W.O #

PK-05-10654-4854-1 PC FREEZER UPRIGHT
PK-05-10655-4855-1 PC REF 2 SECTION REACH IN
PK-05-10656-4856-1 PC REF 2 SECTION REACH IN
PK-05-10652-4852-1 PC REFRIGERATOR-FREEZER

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)
		YES	NO	
15	Inspect door gaskets for damage and proper fit; adjust gaskets as required and lubricate hinges with food grade oil.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	ok
16	Check door gasket heater.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
17	Check box floor for water or ice accumulation.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	yes ok
18	Check box for excessive ice build- up and open seams.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency.

To be performed by: General Maintenance Worker

Additional Notes: