

## PREVENTATIVE MAINTENANCE PROGRAM CHECKLIST

### Condensing Unit

SITE AND BLDG #: NY058-104

MECHANIC  
SIGNATURE:

*nick woffe* DATE: *3/26/19*

LOCATION/RM #:

START TIME:

*7am*

FINISH TIME:

*1pm*

Site Location	WO #	Asset #	PM #	Manufacturer	Model Number	Serial #	Asset Description	Asset Location
NY058-104	2852	10237		Liebert	PFH014A-PL7	1031N201486	J-04 1-pc Condensing Unit	
NY058-104	2854	10238		Liebert		1031n201486	J-04 1-pc Condensing Unit	
NY058-104	2856	10239		Liebert	PFH027-PL7	1031N201589	J-04 1-pc Condensing Unit	
NY058-104	2858	10240		Liebert	PFH027A-PL7	1031N21519	J-04 1-pc Condensing Unit	
NY058-104	2860	10241		Liebert	PFH037A-AL7	1031N201535	J-04 1-pc Condensing Unit	

CHECK POINT	CHECKPOINT DESCRIPTION	TASK COMPLETE		NOTES/ ACTIONS (IF TASK COMPLETE IS CHECKED NO, PROVIDE EXPLANATION)
		YES	NO	
SPECIAL INSTRUCTIONS				
1	In addition to the procedure(s) outlined in this standard, the equipment manufacturer's recommended maintenance procedure(s) and/or instruction(s) shall be strictly adhered to.			
2	Follow lock out/tag out procedures always. De-energize or discharge all hydraulic, electrical, mechanical, or thermal energy prior to beginning work.			
TO BE PERFORMED AT EACH INSPECTION SERVICE				
1	Wash and clean pump. If pump is used in a dirty environment or is pumping something other than clear condensate water, the tank should be removed and cleaned.			
2	Pour enough water into the tank to activate the pump.			
3	Ensure that the pump is in proper working condition. Recommend repair or replacement as needed.			

Note: The technician shall perform any repairs identified during PM up to \$250 (direct labor and direct material cost) per PM occurrence. For any deficiencies found exceeding \$250 open a corrective maintenance (CM) ticket and include the Asset #, WO #, photos, and a detailed description of the deficiency. To be performed by: General Maintenance Worker **Additional Notes:**

